

THIS SITE HAD TO BE EXCAVATED FIRST



AIDING THE MEMBRANE TRANSITION



EVERY PART OF THE PVC MEMBRANE IS HEAT WELDED TOGETHER



CAVITY STEP FLASHING AT THE OTHER END OF THE BUILDING



REMOVING & PROPPING THE BRICKWORK



HEAT WELDING EVERY PART TOGETHER



THE STAIRS ARE ENCAPSULATE & WELDED TO THE CAVITY FLASHING



A BETTER VIEW



RENDERING THE BRICKWORK



THE MAIN PVC MEMBRANE AREAS ARE INSTALLED



WELDING OFF THE BASE TERMINATION



SO CLOSE TO COMPLETION



THE PVC MEMBRANE OVER THE STAIRS COMPLETED



DETAILING THE CHANGES OF DIRECTION



ALL VERY TIME CONSUMING RESULTING IN A PERMANENT SOLUTION



ALL THAT IS REQUIRED NOW IS BRICKWORK, RENDER & PAINT

